NAME

mbio – Format independent input/output library for swath mapping sonar data.

VERSION

Version 5.0

DESCRIPTION

MBIO (**M**ulti**B**eam **I**nput/**O**utput) is a library of functions used for reading and writing swath mapping sonar data files. **MBIO** supports a large number of data formats associated with different institutions and different sonar systems. The purpose of **MBIO** is to allow users to write processing and display programs which are independent of particular data formats and to provide a standard approach to swath mapping sonar data i/o.

AUTHORSHIP

David W. Caress (caress@mbari.org)
Monterey Bay Aquarium Research Institute
Dale N. Chayes (dale@ldeo.columbia.edu)
Lamont-Doherty Earth Observatory

DATA TERMINOLOGY

MBIO handles three types of swath mapping data: beam bathymetry, beam amplitude, and sidescan. Both amplitude and sidescan represent measures of backscatter strength. Beam amplitudes are backscatter values associated with the same preformed beams used to obtain bathymetry; **MBIO** assumes that a bathymetry value exists for each amplitude value and uses the bathymetry beam location for the amplitude. Sidescan is generally constructed with a higher spatial resolution than bathymetry, and carries its own location parameters. In the context of **MB-System** documentation, the discrete values of bathymetry and amplitude are referred to as "beams", and the discrete values of sidescan are referred to as "pixels". An additional difference between "beam" and "pixel" data involves data flagging. An array of "beamflags" is carried by **MBIO** functions which allows the bathymetry (and by extension the amplitude) data to be flagged as bad. The details of the beamflagging scheme are presented below.

VERSION 5 CHANGES

This document describes version 5 releases of **MBIO**. The source code structure used in version 4 **MBIO** had grown complex and difficult to support. In particular, the addition of new i/o modules had become excessively time consuming. Consequently, we have restructured and rewritten much of the library. Most of the changes are internal, but two function calls have disappeared (**mb_put()** and **mb_write()**), and a number of new functions have been added.

A further significant architectural change was implemented for release 5.0.8 in order to support data formats that have no explicit maximum number of beams or pixels. The memory management of arrays used to hold bathymetry, amplitude, and sidescan data has been made dynamic. Now, when data records are encountered that include larger numbers of beams or pixels than will fit in the arrays previously allocated, those arrays are reallocated to the required size. This is handled automatically for all of the internal arrays used by **MBIO** functions. Of course, applications using **MBIO** must allocate arrays that are passed into functions like **mb_read**, **mb_get_all**, and **mb_get** to be populated by the desired data. In order for these arrays to be managed dynamically, the application must first register each array by passing the location of the array pointer to a new function called **mb_register_array**.

OVERVIEW

MBIO opens and initializes sonar data files for reading and writing using the functions **mb_read_init** and **mb_write_init**, respectively. These functions return a pointer to a data structure including all relevent information about the opened file, the control parameters which determine how data is read or written, and

the arrays used for processing the data as it is read or written. This pointer is then passed to the functions used for reading or writing. There is no limit on the number of files which may be opened for reading or writing at any given time in a program.

The **mb_read_init** and **mb_write_init** functions also return initial maximum numbers of bathymetry beams, amplitude beams, and sidescan pixels that can be used to allocate data storage arrays of the appropriate sizes. However, for some data formats there are no specified maximum numbers of beams and pixels, and so in general the required dimensions may increase as data are read. Applications must pass appropriately dimensioned arrays into data extraction routines such as **mb_read**, **mb_get**, and **mb_get_all**. In order to enable dynamic memory management of thse application arrays, the application must first register each array by passing the array pointer location to the function **mb_register_array**.

Data files are closed using the function **mb_close**. All internal and registered arrays are deallocated as part of closing the file.

When it comes to actually reading and writing swath mapping sonar data, **MBIO** has three levels of i/o functionality:

1: Simple reading of swath data files. The primary functions are:
mb_read()
mb_get()
The positions of individual beams and pixels are returned in longitude and latitude by **mb_read()** and in acrosstrack and alongtrack distances by **mb_get()**. Only a limited set of navigation information is returned. Comments are also returned. These functions can be used without any special include files or any knowledge of the actual data structures used by the data formats or **MBIO**.

2: Complete reading and writing of data structures containing all of the available information. Data records may be read or written without extracting any of the information, or the swath data may be passed with the data structure. Several functions exist to extract information from or insert information into the data structures; otherwise, special include files are required to make sense of the sonar-specific data structures passed by level 2 i/o functions. The basic read and write functions that only pass pointers to internal data structures are:
mb_read_ping()
mb_write_ping()
The read and write routines which also extract or insert information are:
mb_get_all()
mb_put_all()
mb_put_comment()
The information extraction and insertion functions are:
mb_insert()
mb_extract()
mb_extract_nav()

mb_insert_nav()
mb_extract_altitude()
mb_insert_altitude()
mb_ttimes()
mb_copyrecord()

3: Buffered reading and writing of data structures containing all of the available information. The primary functions are:

mb_buffer_init()
mb_buffer_close()
mb_buffer_load()
mb_buffer_dump()
mb_buffer_info()
mb_buffer_get_next_data()
mb_buffer_extract()
mb_buffer_insert()
mb_buffer_get_next_nav()
mb_buffer_extract_nav()
mb_buffer_insert_nav()

The level 1 **MBIO** functions allow users to read sonar data independent of format, with the limitation that only a limited set of navigation information is passed. Thus, some of the information contained in certain data formats (e.g. the "heave" value in Hydrosweep DS data) is not passed by **mb_read()** or **mb_get()**. In general, the level 1 functions are useful for applications such as graphics which require only the navigation and the depth and/or backscatter values.

The level 2 functions (**mb_get_all()** and **mb_put_all()**) read and write the complete data structures, translate the data to internal data structures associated with each of the supported sonar systems, and pass pointers to these internal data structures. Additional functions allow a variety of information to be extracted from or inserted into the data structures (e.g. mb_extract() and mb_insert()). Additional information may be accessed using special include files to decode the data structures. The great majority of processing programs use level 2 functions.

The level 3 functions provide buffered reading and writing which is useful for applications that generate output files and need access to multiple pings at a time. In addition to reading (**mb_buffer_load()**) and writing (**mb_buffer_dump()**), functions exist for extracting information from the buffer (**mb_buffer_extract()**) and inserting information into the buffer (**mb_buffer_insert()**).

MBIO supports swath data in a number of different formats, each specified by a unique id number. The function **mb_format()** determines if a format id is valid. A set of similar functions returns information about the specified format (e.g. **mb_format_description()**, **mb_format_system()**, **mb_format_description()**, **mb_format_dimensions()**, **mb_format_flags()**, **mb_format_source()**, **mb_format_beamwidth()**).

Some **MB-System** programs can process multiple data files specified in "datalist" files. Each line of a datalist file contains a file path and the corresponding **MBIO** format id. Datalist files can be recursive and can contain comments. The functions used to extract input swath data file paths from datalist files includes **mb_datalist_open()**, **mb_datalist_read()**, and **mb_datalist_close()**.

A number of other **MBIO** functions dealing with default values for important parameters, error messages, memory management, and time conversions also exist and are discussed below.

SUPPORTED SWATH SONAR SYSTEMS

Each swath mapping sonar system outputs a data stream which includes some values or parameters unique to that system. In general, a number of different data formats have come into use for data from each of the

sonar systems; many of these formats include only a subset of the original data stream. Internally, **MBIO** recognizes which sonar system each data format is associated with and uses a data structure including the complete data stream for that sonar. Consequently, it is possible to read and write the complete data stream when using the level 2 or 3 **MBIO** functions. At present, formats associated with the following sonars are supported:

SeaBeam "classic" 16 beam multibeam sonar
Hydrosweep DS 59 beam multibeam sonar
Hydrosweep MD 40 beam mid-depth multibeam sonar
SeaBeam 2000 multibeam sonar
SeaBeam 2112, 2120, and 2130 multibeam sonars
Simrad EM12, EM121, EM950, and EM1000 multibeam sonars
Simrad EM120, EM300, EM1002, and EM3000 multibeam sonars
Hawaii MR-1 shallow tow interferometric sonar
ELAC Bottomchart 1180 and 1050 multibeam sonars
ELAC/SeaBeam Bottomchart Mk2 1180 and 1050 multibeam sonars
Reson Seabat 9001/9002 multibeam sonars
Reson Seabat 8101 multibeam sonars
Simrad/Mesotech SM2000 multibeam sonars
WHOI DSL AMS-120 deep tow interferometric sonar AMS-60 interferometric sonar

SUPPORTED FORMATS

The following swath mapping sonar data formats are supported in this version of **MBIO**:

MBIO Data Format ID: 11
Format name: MBF_SBSIOMRG
Informal Description: SIO merge Sea Beam
Attributes: Sea Beam, bathymetry, 16 beams, binary, uncentered, SIO.

MBIO Data Format ID: 12
Format name: MBF_SBSIOCEN
Informal Description: SIO centered Sea Beam
Attributes: Sea Beam, bathymetry, 19 beams, binary, centered, SIO.

MBIO Data Format ID: 13
Format name: MBF_SBSIOLSI
Informal Description: SIO LSI Sea Beam
Attributes: Sea Beam, bathymetry, 19 beams, binary, centered, obsolete, SIO.

MBIO Data Format ID: 14
Format name: MBF_SBURICEN
Informal Description: URI Sea Beam
Attributes: Sea Beam, bathymetry, 19 beams, binary, centered, URI.

MBIO Data Format ID: 15
Format name: MBF_SBURIVAX
Informal Description: URI Sea Beam from VAX
Attributes: Sea Beam, bathymetry, 19 beams,
binary, centered,
VAX byte order, URI.

MBIO Data Format ID: 16
Format name: MBF_SBSIOSWB
Informal Description: SIO Swath-bathy SeaBeam
Attributes: Sea Beam, bathymetry, 19 beams,
binary, centered, SIO.

MBIO Data Format ID: 17
Format name: MBF_SBIFREMR
Informal Description: IFREMER Archive SeaBeam
Attributes: Sea Beam, bathymetry, 19 beams,
ascii, centered, IFREMER.

MBIO Data Format ID: 21
Format name: MBF_HSATLRAW
Informal Description: Raw Hydrosweep
Attributes: Hydrosweep DS, bathymetry and
amplitude, 59 beams, ascii,
Atlas Electronik.

MBIO Data Format ID: 22
Format name: MBF_HSLDEDMB
Informal Description: EDMB Hydrosweep
Attributes: Hydrosweep DS, bathymetry,
59 beams, binary, NRL.

MBIO Data Format ID: 23
Format name: MBF_HSURICEN
Informal Description: URI Hydrosweep
Attributes: Hydrosweep DS, 59 beams,
bathymetry, binary, URI.

MBIO Data Format ID: 24
Format name: MBF_HSLDEOIH
Informal Description: L-DEO in-house binary Hydrosweep
Attributes: Hydrosweep DS, 59 beams,
bathymetry and amplitude,
binary, centered, L-DEO.

MBIO Data Format ID: 25
Format name: MBF_HSURIVAX
Informal Description: URI Hydrosweep from VAX
Attributes: Hydrosweep DS, 59 beams,
bathymetry, binary, VAX byte
order, URI.

MBIO Data Format ID: 32
Format name: MBF_SB2000SB

Informal Description: SIO Swath-bathy SeaBeam 2000
Attributes: SeaBeam 2000, bathymetry, 121 beams, binary, SIO.

MBIO Data Format ID: 33
Format name: MBF_SB2000SS
Informal Description: SIO Swath-bathy SeaBeam 2000
Attributes: SeaBeam 2000, sidescan, 1000 pixels for 4-bit sidescan, 2000 pixels for 12+-bit sidescan, binary, SIO.

MBIO Data Format ID: 41
Format name: MBF_SB2100RW
Informal Description: SeaBeam 2100 series vender format
Attributes: SeaBeam 2100, bathymetry, amplitude and sidescan, 151 beams and 2000 pixels, ascii with binary sidescan, SeaBeam Instruments.

MBIO Data Format ID: 42
Format name: MBF_SB2100B1
Informal Description: SeaBeam 2100 series vender format
Attributes: SeaBeam 2100, bathymetry, amplitude and sidescan, 151 beams bathymetry, 2000 pixels sidescan, binary, SeaBeam Instruments and L-DEO.

MBIO Data Format ID: 43
Format name: MBF_SB2100B2
Informal Description: SeaBeam 2100 series vender format
Attributes: SeaBeam 2100, bathymetry and amplitude, 151 beams bathymetry, binary, SeaBeam Instruments and L-DEO.

MBIO Data Format ID: 51
Format name: MBF_EMOLDRAW
Informal Description: Old Simrad vendor multibeam format
Attributes: Simrad EM1000, EM12S, EM12D, and EM121 multibeam sonars, bathymetry, amplitude, and sidescan, 60 beams for EM1000, 81 beams for EM12S/D, 121 beams for EM121, variable pixels, ascii + binary, Simrad.

MBIO Data Format ID: 53
Format name: MBF_EM12IFRM
Informal Description: IFREMER TRISMUS format for Simrad EM12

Attributes: Simrad EM12S and EM12D, bathymetry, amplitude, and sidescan 81 beams, variable pixels, binary, IFREMER.

MBIO Data Format ID: 54
Format name: MBF_EM12DARW
Informal Description: Simrad EM12S RRS Darwin processed format
Attributes: Simrad EM12S, bathymetry and amplitude, 81 beams, binary, Oxford University.

MBIO Data Format ID: 56
Format name: MBF_EM300RAW
Informal Description: Simrad current multibeam vendor format
Attributes: Simrad EM120, EM300, EM1002, EM3000, bathymetry, amplitude, and sidescan, up to 254 beams, variable pixels, ascii + binary, Simrad.

MBIO Data Format ID: 57
Format name: MBF_EM300MBA
Informal Description: Simrad multibeam processing format
Attributes: Old and new Simrad multibeams, EM12S, EM12D, EM121, EM120, EM300, EM100, EM1000, EM950, EM1002, EM3000, bathymetry, amplitude, and sidescan, up to 254 beams, variable pixels, ascii + binary, MBARI.

MBIO Data Format ID: 58
Format name: MBF_EM710RAW
Informal Description: Simrad current multibeam vendor format
Attributes: Simrad EM710, bathymetry, amplitude, and sidescan, up to 400 beams, variable pixels, binary, Simrad.

MBIO Data Format ID: 59
Format name: MBF_EM710MBA
Informal Description: Simrad current multibeam vendor format
Attributes: Simrad EM710, bathymetry, amplitude, and sidescan, up to 400 beams, variable pixels, binary, Simrad.

MBIO Data Format ID: 61
Format name: MBF_MR1PRHIG
Informal Description: SOEST MR1 post processed format
Attributes: SOEST MR1, bathymetry and

sidescan, variable beams and
pixels, xdr binary, SOEST,
University of Hawaii.

MBIO Data Format ID: 62
Format name: MBF_MR1ALDEO
Informal Description: L-DEO MR1 post processed
format with travel times
Attributes: L-DEO MR1, bathymetry and
sidescan, variable beams
and pixels, xdr binary, L-DEO.

MBIO Data Format ID: 63
Format name: MBF_MR1BLDEO
Informal Description: L-DEO small MR1 post processed
format with travel times
Attributes: L-DEO MR1, bathymetry and sidescan,
variable beams and pixels,
xdr binary, L-DEO.

MBIO Data Format ID: 64
Format name: MBF_MR1PRVR2
Informal Description: SOEST MR1 post processed format
Attributes: SOEST MR1, bathymetry and sidescan,
variable beams and pixels, xdr binary,
SOEST, University of Hawaii.

MBIO Data Format ID: 71
Format name: MBF_MBLDEOIH
Informal Description: L-DEO in-house generic multibeam
Attributes: Data from all sonar systems,
bathymetry, amplitude and
sidescan, variable beams and
pixels, binary, centered, L-DEO.

MBIO Data Format ID: 75
Format name: MBF_MBNETCDF
Informal Description: CARAIBES CDF multibeam
Attributes: Data from all sonar systems,
bathymetry only, variable
beams, netCDF, IFREMER.

MBIO Data Format ID: 81
Format name: MBF_CBAT9001
Informal Description: Reson SeaBat 9001 shallow
water multibeam
Attributes: 60 beam bathymetry and
amplitude, binary, University
of New Brunswick.

MBIO Data Format ID: 82
Format name: MBF_CBAT8101
Informal Description: Reson SeaBat 8101 shallow
water multibeam

Attributes: 101 beam bathymetry and amplitude, binary, SeaBeam Instruments.

MBIO Data Format ID: 83
Format name: MBF_HYPC8101
Informal Description: Reson SeaBat 8101 shallow water multibeam
Attributes: 101 beam bathymetry, ASCII, read-only, Coastal Oceanographics.

MBIO Data Format ID: 84
Format name: MBF_XTFR8101
Informal Description: XTF format Reson SeaBat 81XX
Attributes: 240 beam bathymetry and amplitude, 1024 pixel sidescan binary, read-only, Triton-Elics.

MBIO Data Format ID: 88
Format name: MBF_RESON7KR
Informal Description: Reson 7K multibeam vendor format
Attributes: Reson 7K series multibeam sonars, bathymetry, amplitude, three channels sidescan, and subbottom up to 254 beams, variable pixels, binary, Reson.

MBIO Data Format ID: 91
Format name: MBF_BCHRTUNB
Informal Description: Elac BottomChart shallow water multibeam
Attributes: 56 beam bathymetry and amplitude, binary, University of New Brunswick.

MBIO Data Format ID: 92
Format name: MBF_ELMK2UNB
Informal Description: Elac BottomChart MkII shallow water multibeam
Attributes: 126 beam bathymetry and amplitude, binary, University of New Brunswick.

MBIO Data Format ID: 93
Format name: MBF_BCHRXUNB
Informal Description: Elac BottomChart shallow water multibeam
Attributes: 56 beam bathymetry and amplitude, binary, University of New Brunswick.

MBIO Data Format ID: 94

Format name: MBF_L3XSERAW
Informal Description: ELAC/SeaBeam XSE vendor format
Attributes: Bottomchart MkII 50 kHz and 180 kHz multibeam, SeaBeam 2120 20 KHz multibeam, bathymetry, amplitude and sidescan, variable beams and pixels, binary, L3 Communications (Elac Nautik and SeaBeam Instruments).

MBIO Data Format ID: 101
Format name: MBF_HSMDARAW
Informal Description: Atlas HSMD medium depth multibeam raw format
Attributes: 40 beam bathymetry, 160 pixel sidescan, XDR (binary), STN Atlas Elektronik.

MBIO Data Format ID: 102
Format name: MBF_HSMDLDIH
Informal Description: Atlas HSMD medium depth multibeam processed format
Attributes: 40 beam bathymetry, 160 pixel sidescan, XDR (binary), L-DEO.

MBIO Data Format ID: 111
Format name: MBF_DSL120SF
Informal Description: WHOI DSL AMS-120 processed format
Attributes: 2048 beam bathymetry, 8192 pixel sidescan, binary, single files, WHOI DSL.

MBIO Data Format ID: 112
Format name: MBF_DSL120PF
Informal Description: WHOI DSL AMS-120 processed format
Attributes: 2048 beam bathymetry, 8192 pixel sidescan, binary, parallel bathymetry and amplitude files, WHOI DSL.

MBIO Data Format ID: 121
Format name: MBF_GSFGENMB
Informal Description: SAIC Generic Sensor Format (GSF)
Attributes: variable beams, bathymetry and amplitude, binary, single files, SAIC.

MBIO Data Format ID: 131
Format name: MBF_MSTIFFSS
Informal Description: MSTIFF sidescan format
Attributes: variable pixels, sidescan, binary TIFF variant, single files, Sea Scan.

MBIO Data Format ID: 132
Format name: MBF_EDGJSTAR
Informal Description: Edgetech Jstar format
Attributes: variable pixels, dual frequency sidescan and subbottom, binary SEGY variant, single files, low frequency sidescan returned as survey data, Edgetech.

MBIO Data Format ID: 133
Format name: MBF_EDGJSTR2
Informal Description: Edgetech Jstar format
Attributes: variable pixels, dual frequency sidescan and subbottom, binary SEGY variant, single files, high frequency sidescan returned as survey data, Edgetech.

MBIO Data Format ID: 141
Format name: MBF_OICGEODA
Informal Description: OIC swath sonar format
Attributes: variable beam bathymetry and amplitude, variable pixel sidescan, binary, Oceanic Imaging Consultants

MBIO Data Format ID: 142
Format name: MBF_OICMBARI
Informal Description: OIC-style extended swath sonar format
Attributes: variable beam bathymetry and amplitude, variable pixel sidescan, binary, MBARI

MBIO Data Format ID: 151
Format name: MBF_OMGHDCSJ
Informal Description: UNB OMG HDCS format (the John Hughes Clarke format)
Attributes: variable beam bathymetry and amplitude, variable pixel sidescan, binary, UNB

MBIO Data Format ID: 160
Format name: MBF_SEGYSEGY
Informal Description: SEGY seismic data format
Attributes: seismic or subbottom trace data, single beam bathymetry, nav, binary, SEG (SIOSEIS variant)

MBIO Data Format ID: 161
Format name: MBF_MGD77DAT
Informal Description: NGDC MGD77 underway geophysics format

Attributes: single beam bathymetry, nav, magnetics, gravity, ascii, NOAA NGDC

MBIO Data Format ID: 162
Format name: MBF_ASCIIXYZ
Informal Description: Generic XYZ sounding format
Attributes: XYZ (lon lat depth) ASCII soundings, generic

MBIO Data Format ID: 163
Format name: MBF_ASCIIYXZ
Informal Description: Generic YXZ sounding format
Attributes: YXZ (lat lon depth) ASCII soundings, generic

MBIO Data Format ID: 164
Format name: MBF_HYDROB93
Informal Description: NGDC binary hydrographic sounding format
Attributes: XYZ (lon lat depth) binary soundings

MBIO Data Format ID: 165
Format name: MBF_MBARIROV
Informal Description: MBARI ROV navigation format
Attributes: ROV navigation, MBARI

MBIO Data Format ID: 166
Format name: MBF_MBPRONAV
Informal Description: MB-System simple navigation format
Attributes: navigation, MBARI

MBIO Data Format ID: 167
Format name: MBF_MBNETCDF
Informal Description: CARAIBES CDF navigation
Attributes: netCDF, IFREMER.

MBIO Data Format ID: 168
Format name: MBF_ASCIIXYT
Informal Description: Generic XYT sounding format
Attributes: XYT (lon lat topography) ASCII soundings, generic

MBIO Data Format ID: 169
Format name: MBF_ASCIIYXT
Informal Description: Generic YXT sounding format
Attributes: YXT (lat lon topograpy) ASCII soundings, generic

MBIO Data Format ID: 170
Format name: MBF_MBARROV2
Informal Description: MBARI ROV navigation format

Attributes: ROV navigation, MBARI

MBIO Data Format ID: 171
Format name: MBF_HS10JAMS
Informal Description: Furuno HS-10 multibeam format,
Attributes: 45 beams bathymetry and amplitude,
ascii, JAMSTEC

MBIO Data Format ID: 181
Format name: MBF_SAMESURF
Informal Description: SAM Electronics SURF format.
Attributes: variable beams, bathymetry,
amplitude, and sidescan,
binary, single files, SAM Electronics (formerly Krupp-Atlas Electronik).

MBIO Data Format ID: 182
Format name: MBF_HSDS2RAW
Informal Description: STN Atlas raw multibeam format
Attributes: STN Atlas multibeam sonars,
Hydrosweep DS2, Hydrosweep MD,
Fansweep 10, Fansweep 20,
bathymetry, amplitude, and sidescan,
up to 1440 beams and 4096 pixels,
XDR binary, STN Atlas.

MBIO Data Format ID: 183
Format name: MBF_HSDS2LAM
Informal Description: L-DEO HSDS2 processing format
Attributes: STN Atlas multibeam sonars,
Hydrosweep DS2, Hydrosweep MD,
Fansweep 10, Fansweep 20,
bathymetry, amplitude, and sidescan,
up to 1440 beams and 4096 pixels,
XDR binary, L-DEO.

MBIO Data Format ID: 222
Format name: MBF_SWPLSSXP
Informal Description: SEA interferometric processed data format
Attributes: Submetrix Interferometers,
SWATHplus-L, SWATHplus-M, SWATHplus-H,
Bathyswath-1, Bathyswath-2,
bathymetry and amplitude, SXP binary.

The institutional acronyms used above have the following meanings:

L-DEO	Lamont-Doherty Earth Observatory
MBARI	Monterey Bay Aquarium Research Institute
SIO	Scripps Institution of Oceanography
WHOI	Woods Hole Oceanographic Institution
URI	University of Rhode Island
NRL	Naval Research Laboratory
UNB	University of New Brunswick
UH	University of Hawaii
NOAA	National Oceans and Atmospheres Agency

NGDC National Geophysical Data Center
USGS United States Geological Survey
IFREMER French government agency responsible for operation of French oceanographic research fleet.

FUNCTION STATUS AND ERROR CODES

All of the **MBIO** functions return an integer status value with the convention that:

status = 1: success
status = 0: failure

All **MBIO** functions also pass an error value argument which gives somewhat more information about problems than the status value. The full suite of possible error values and the associated error messages are:

error = 0: "No error",
error = −1: "Time gap in data",
error = −2: "Data outside specified location bounds",
error = −3: "Data outside specified time interval",
error = −4: "Ship speed too small",
error = −5: "Comment record",
error = −6: "Neither a data record nor a comment record",
error = −7: "Unintelligible data record",
error = −8: "Ignore this data",
error = −9: "No data requested for buffer load",
error = −10: "Data buffer is full",
error = −11: "No data was loaded into the buffer",
error = −12: "Data buffer is empty",
error = −13: "No data was dumped from the buffer"
error = −14: "No more survey data records in buffer"
error = −15: "Data inconsistencies prevented inserting data into storage structure"
error = 1: "Unable to allocate memory, initialization failed",
error = 2: "Unable to open file, initialization failed",
error = 3: "Illegal format identifier, initialization failed",
error = 4: "Read error, probably end-of-file",
error = 5: "Write error",
error = 6: "No data in specified location bounds",
error = 7: "No data in specified time interval",
error = 8: "Invalid MBIO descriptor",
error = 9: "Inconsistent usage of MBIO descriptor",
error = 10: "No pings binned but no fatal error - this should not happen!",
error = 11: "Invalid data record type specified for writing",
error = 12: "Invalid control parameter specified by user",
error = 13: "Invalid buffer id",
error = 14: "Invalid system id − this should not happen!"
error = 15: "This data file is not in the specified format!"

In general, programs should treat negative error values as non-fatal (reading and writing can continue) and positive error values as fatal (the data files should be closed and the program terminated).

FUNCTION VERBOSITY

All of the **MBIO** functions are passed a *verbose* parameter which controls how much debugging information is output to standard error. If *verbose* is 0 or 1, the **MBIO** functions will be silent. If *verbose* is 2, then each function will output information as it is entered and as it returns, along with the parameter values passed into and returned out of the function. Greater values of *verbose* will cause additional information to be output, including values at various stages of data processing during read and write operations. In general, programs using **MBIO** functions should adopt the following verbosity conventions:

verbose = 0: "silent" or near-"silent" execution
verbose = 1: simple output including
program name, version
and simple progress updates
verbose >= 2: debug mode with copious output
including every function call
and status listings

INITIALIZATION AND CLOSING FUNCTIONS

int **mb_read_init**(
int *verbose*,
char **file*,
int *format*,
int *pings*,
int *lonflip*,
double *bounds[4]*,
int *btime_i[7]*,
int *etime_i[7]*,
double *speedmin*,
double *timegap*,
char ***mbio_ptr*,
double **btime_d*,
double **etime_d*,
int **beams_bath*,
int **beams_amp*,
int **pixels_ss*,
int **error*);

The function **mb_read_init** initializes the data file to be read and the data structures required for reading the data. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

file: input filename
format: input **MBIO** data format id
pings: ping averaging
lonflip: longitude flipping
bounds: location bounds of acceptable data
btime_i: beginning time of acceptable data
etime_i: ending time of acceptable data
speedmin: minimum ship speed of acceptable data
timegap: maximum time allowed before data gap

The format identifier *format* specifies which of the supported data formats is being read or written; the currently supported formats are listed in the "SUPPORTED FORMATS" section.

The *pings* parameter determines whether and how pings are averaged as part of data input. This parameter

is used only by the functions **mb_read** and **mb_get**; **mb_get_all** and **mb_buffer_load** do not average pings. If *pings* = 1, then no ping averaging will be done and each ping read will be returned unaltered by the reading function. If *pings* > 1, then the navigation and beam data for *pings* pings will be read, averaged, and returned as the data for a single ping. If *pings* = 0, then the ping averaging will be varied so that the along-track distance between averaged pings is as close as possible to the across-track distance between beams.

The *lonflip* paramenter determines the range in which longitude values are returned:
lonflip = −1 : −360 to 0
lonflip = 0 : −180 to 180
lonflip = 1 : 0 to 360

The *bounds* array sets the area within which data are desired. Data which lie outside the area specified by *bounds* will be returned with an error by the reading function. The functions **mb_read**, **mb_get** and **mb_get_all** use the *bounds* array; the function **mb_buffer_load** does no location checking.
bounds[0] : minimum longitude
bounds[1] : maximum longitude
bounds[2] : minimum latitude
bounds[3] : maximum latitude

The *btime_i* array sets the desired beginning time for the data and the *etime_i* array sets the desired ending time. If the beginning time is earlier than the ending time, then any data with a time stamp before the beginning time or after the ending time will be returned with an MB_ERROR_OUT_TIME error by the reading function. If the beginning time is after the ending time, then data with time stamps between the ending and beginning time are returned with an error. This scheme allows time windowing outside or inside a specified interval. The functions **mb_read**, **mb_get** and **mb_get_all** use the *btime_i* and *btime_i* arrays; the function **mb_buffer_load** does no time checking.
btime[0] : year
btime[1] : month
btime[2] : day
btime[3] : hour
btime[4] : minute
btime[5] : second
btime[6] : microsecond
etime[0] : year
etime[1] : month
etime[2] : day
etime[3] : hour
etime[4] : minute
etime[5] : second
etime[6] : microsecond

The *speedmin* parameter sets the minimum acceptable ship speed for the data. If the ship speed associated with any ping is less than *speedmin*, then that data will be returned with an error by the reading function. This is used to eliminate data collected while a ship is on station is a simple way. The functions **mb_read**, **mb_get** and **mb_get_all** use the *speedmin* value; the function **mb_buffer_load** does no speed checking.

The *timegap* parameter sets the minimum time gap allowed before a gap in the data is declared. Ping averaging is not done across data gaps; an error is returned when time gaps are encountered. The functions **mb_read** and **mb_get** use the *timegap* value; the functions **mb_get_all** and **mb_buffer_load** do no ping averaging and thus have no need to check for time gaps.

The returned values are:
mbio_ptr: pointer to an **MBIO** descriptor structure

btime_d: desired beginning time in seconds since 1/1/70 00:00:0
etime_d: desired ending time in seconds since 1/1/70 00:00:0
beams_bath: maximum number of bathymetry beams
beams_amp: maximum number of amplitude beams
pixels_ss: maximum number of sidescan pixels
error: error value

The structure pointed to by *mbio_ptr* holds the file descriptor and all of the control parameters which govern how the data is read; this pointer must be provided to the functions **mb_read**, **mb_get**, **mb_get_all**, or **mb_buffer_load** to read data. The values *beams_bath*, *beams_amp*, and *pixels_ss* return initial estimates of the maximum number of bathymetry and amplitude beams and sidescan pixels, respectively, that the specified data format may contain. In general, *beams_amp* will either be zero or equal to *beams_bath*. The values *btime_d* and *etime_d* give the desired beginning and end times of the data converted to seconds since 00:00:00 on January 1, 1970; **MBIO** uses these units to calculate time internally.

For most data formats, the initial maximum beam and pixel dimensions will not change. However, a few formats support both variable and arbitrarily large numbers of beams and/or pixels, and so applications must be capable of handling dynamic changes in the numbers of beams and pixels. The arrays allocated internally in the *mbio_ptr* structure are automatically increased when necessary. However, in order to successfully extract swath data using *mb_get*, *mb_get_all*, *mb_read*, or *mb_extract*, an application must also provide pointers to arrays large enough to hold the current maximum numbers of bathymetry beams, amplitude beams, and sidescan pixels. The function *mb_register_ioarray* allows applications to register array pointers so that these arrays are also dynamically allocated by *MBIO*. Registered arrays will be managed as data are read and then freed when **mb_close** is called.

A status value indicating success or failure is returned; an error value argument passes more detailed information about initialization failures.

---

int **mb_write_init**(
int *verbose*,
char **file*,
int *format*,
char ***mbio_ptr*,
int **beams_bath*,
int **beams_amp*,
int **pixels_ss*,
int **error*);

The function **mb_write_init** initializes the data file to be written and the data structures required for writing the data. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

file: output filename
format: output **MBIO** data format id

The returned values are:

mbio_ptr: pointer to a structure describing the output file
beams_bath: maximum number of bathymetry beams
beams_back: maximum number of backscatter beams
error: error value

The structure pointed to by *mbio_ptr* holds the output file descriptor; this pointer must be provided to the functions **mb_write**, **mb_put**, **mb_put_all**, or **mb_buffer_dump** to write data. The values *beams_bath*, *beams_amp*, and *pixels_ss* return the maximum number of bathymetry and amplitude beams and sidescan pixels, respectively, that the specified data format may contain. In general, *beams_amp* will either be zero or equal to *beams_bath*. In order to successfully write data, the calling program must provide pointers to arrays large enough to hold *beams_bath* bathymetry values, *beams_amp* amplitude values, and *pixels_ss* sidescan values.

For most data formats, the initial maximum beam and pixel dimensions will not change. However, a few formats support both variable and arbitrarily large numbers of beams and/or pixels, and so applications must be capable of handling dynamic changes in the numbers of beams and pixels. The arrays allocated internally in the *mbio_ptr* structure are automatically increased when necessary. However, in order to successfully insert modified swath data using *mb_put*, *mb_put_all*, or *mb_insert*, an application must also provide pointers to arrays large enough to hold the current maximum numbers of bathymetry beams, amplitude beams, and sidescan pixels. The function *mb_register_ioarray* allows applications to register array pointers so that these arrays are also dynamically allocated by *MBIO*. Registered arrays will be managed as data are read and written and then freed when **mb_close** is called.

A status value indicating success or failure is returned; an error value argument passes more detailed information about initialization failures.

---

int **mb_register_array**(
int *verbose*,
void **mbio_ptr*,
int *type*,
int *size*,
void ***handle*,
int **error*)

Registers an array pointer **handle* so that the size of the allocated array can be managed dynamically by **MBIO**. Note that the location ***handle of the array pointer must be supplied, not the pointer value *handle. The pointer value *handle should initially be NULL. The type value indicates whether this array is to be dimensioned according to the maximum number of bathymetry beams (type = 1), amplitude beams (type = 2), or sidescan pixels (type = 3). The size value indicates the size of each element array in bytes (e.g. a char array has size = 1, a short array has size = 2, an int array or a float array have size = 4, and a double array has size = 8). The array is associated with the* **MBIO** *descriptor mbio_ptr, and is freed when mb_close is called for this particular mbio_ptr.*

---

int **mb_close***(*
int verbose,
*char *mbio_ptr,*
*int *error)*

Closes the data file listed in the **MBIO** *descriptor pointed to by mbio_ptr and releases all specially allocated memory, including all application arrays registered using* **mb_register_array**.. *The verbose value controls the standard error output verbosity of the function. A status value indicating success or failure is returned; an error value argument passes more detailed information about failures.*

LEVEL 1 FUNCTIONS

---

int **mb_read**(
int *verbose*,
char **mbio_ptr*,

int **kind*,
int **pings*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **distance*,
double **altitude*,
double **sonardepth*,
int **nbath*,
int **namp*,
int **nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathlon*,
double **bathlat*,
double **ss*,
double **sslon*,
double **sslat*,
char **comment*,
int **error*);

The function **mb_read** reads, processes, and returns sonar data according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. A number of different data record types are recognized by **MB-System**, but **mb_read()** only returns survey and comment data records. The *kind* value indicates which type of record has been read. The data is in the form of bathymetry, amplitude, and sidescan values combined with the longitude and latitude locations of the bathymetry and sidescan measurements (amplitudes are coincident with the bathymetry).

The return values are:

kind: kind of data record read

1	survey data
2	comment
>=3	other data that cannot be passed by **mb_read**

pings: number of pings averaged to give current data

time_i: time of current ping
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond

time_d: time of current ping in seconds since 1/1/70 00:00:00

navlon: longitude

navlat: latitude

speed: ship speed in km/s

heading: ship heading in degrees

distance: distance along shiptrack since last

	ping in km
altitude:	altitude of sonar above seafloor in m
sonardepth:	depth of sonar in m
nbath:	number of bathymetry values
namp:	number of amplitude values
nss:	number of sidescan values
beamflag:	array of bathymetry flags
bath:	array of bathymetry values in meters
amp:	array of amplitude values in unknown units
bathlon:	array of of longitude values corresponding to bathymetry
bathlat:	array of of latitude values corresponding to bathymetry
ss:	array of sidescan values in unknown units
sslon:	array of of longitude values corresponding to sidescan
sslat:	array of of latitude values corresponding to sidescan
comment:	comment string
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about read failures.

---

int **mb_get**(
int *verbose*,
char **mbio_ptr*,
int **kind*,
int **pings*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **distance*,
double **altitude*,
double **sonardepth*,
int **nbath*,
int **namp*,
int **nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
char **comment*,
int **error*);

The function **mb_get** reads, processes, and returns sonar data according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. A number of different data record types are recognized by **MB-System**, but **mb_get()** only returns survey and comment data records. The *kind* value indicates which type of record has been read. The data is in the form of bathymetry, amplitude, and sidescan values combined with the acrosstrack and alongtrack distances relative to the navigation of the bathymetry and sidescan measurements (amplitudes are coincident with the bathymetry values).

The return values are:

kind:	kind of data record read 1 survey data 2 comment >=3 other data that cannot be passed by **mb_get**
pings:	number of pings averaged to give current data
time_i:	time of current ping *time_i*[0]: year *time_i*[1]: month *time_i*[2]: day *time_i*[3]: hour *time_i*[4]: minute *time_i*[5]: second *time_i*[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
distance:	distance along shiptrack since last ping in km
altitude:	altitude of sonar above seafloor in m
sonardepth:	depth of sonar in m
nbath:	number of bathymetry values
namp:	number of amplitude values
nss:	number of sidescan values
beamflag:	array of bathymetry flags
bath:	array of bathymetry values in meters
amp:	array of amplitude values in unknown units
bathacrosstrack:	array of of acrosstrack distances in meters corresponding to bathymetry
bathalongtrack:	array of of alongtrack distances in meters corresponding to bathymetry
ss:	array of sidescan values in unknown units
ssacrosstrack:	array of of acrosstrack distances in meters corresponding to sidescan
ssacrosstrack:	array of of alongtrack distances in meters corresponding to sidescan
comment:	comment string
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about read failures.

LEVEL 2 FUNCTIONS

int **mb_read_ping**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
int **kind*,
int **error*);

The function **mb_read_ping** reads and returns sonar data according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The data is returned one record at a time; no averaging is performed. A pointer to a data structure containing all of the data read is returned as *store_ptr*; the form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record has been read.

The return values are:

store_ptr: pointer to complete data structure

kind: kind of data record read

1	survey data
2	comment
3	header
4	calibrate
5	mean sound speed
6	SVP
7	standby
8	nav source
9	parameter
10	start
11	stop
12	nav
13	run parameter
14	clock
15	tide
16	height
17	heading
18	attitude
19	ssv
20	angle
21	event
22	history
23	summary
24	processing parameters
25	sensor parameters
26	navigation error
27	uninterpretable line

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about read failures.

---

int **mb_write_ping**(
int *verbose*,
char **mbio_ptr*,

char **store_ptr*,
int **error*);

The function **mb_write_ping** writes sonar data to the file listed in the **MBIO** descriptor pointed to by *MBIO_ptr*. The *verbose* value controls the standard error output verbosity of the function. A pointer to a data structure containing all of the data read is passed as *store_ptr*; the form of the data structure is determined by the sonar system associated with the format of the data being written. The values to be output are:

store_ptr: pointer to complete data structure

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about write failures.

---

int **mb_get_store**(
int *verbose*,
char **mbio_ptr*,
char ***store_ptr*,
int **error*);

The function **mb_get_store()** returns a pointer **store_ptr* to the data storage structure associated with a particular **MBIO** descriptor *mbio_ptr*. The **mb_read_init()** and **mb_write_init()** functions both allocate one of these internal storage structures. The form of the data structure is determined by the sonar system associated with the format of the data being written. Storage structure pointers must be passed to level two **MBIO** functions such as **mb_write_ping()** and **mb_insert()**. The *verbose* value controls the standard error output verbosity of the function.

The return values are:

store_ptr: pointer to complete data structure
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_get_all**(
int *verbose*,
char **mbio_ptr*,
char ***store_ptr*,
int **kind*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **distance*,
double **altitude*,
double **sonardepth*,
int **nbath*,
int **namp*,

int **nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
char **comment*,
int **error*);

The function **mb_get_all** reads and returns sonar data according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The data is returned one record at a time; no averaging is performed. A pointer to a data structure containing all of the data read is returned as *store_ptr*; the form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record has been read. Additional data is returned if the data record is survey data (navigation, bathymetry, amplitude, and sidescan), navigation data (navigation only), or comment data (comment only).

The return values are:

store_ptr: pointer to complete data structure

kind: kind of data record read

1	survey data
2	comment
3	header
4	calibrate
5	mean sound speed
6	SVP
7	standby
8	nav source
9	parameter
10	start
11	stop
12	nav
13	run parameter
14	clock
15	tide
16	height
17	heading
18	attitude
19	ssv
20	angle
21	event
22	history
23	summary
24	processing parameters
25	sensor parameters
26	navigation error
27	uninterpretable line

time_i: time of current ping
time_i[0]: year
time_i[1]: month

	time_i[2]: day
	time_i[3]: hour
	time_i[4]: minute
	time_i[5]: second
	time_i[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
distance:	distance along shiptrack since last ping in km
altitude:	altitude of sonar above seafloor in m
sonardepth:	depth of sonar in m
nbath:	number of bathymetry values
namp:	number of amplitude values
nss:	number of sidescan values
beamflag:	array of bathymetry flags
bath:	array of bathymetry values in meters
amp:	array of amplitude values in unknown units
bathacrosstrack:	array of of acrosstrack distances in meters corresponding to bathymetry
bathalongtrack:	array of of alongtrack distances in meters corresponding to bathymetry
ss:	array of sidescan values in unknown units
ssacrosstrack:	array of of acrosstrack distances in meters corresponding to sidescan
ssacrosstrack:	array of of alongtrack distances in meters corresponding to sidescan
comment:	comment string
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about read failures.

---

int **mb_put_all**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
int *usevalues*,
int *kind*,
int *time_i[7]*,
double *time_d*,
double *navlon*,
double *navlat*,
double *speed*,
double *heading*,
int *nbath*,
int *namp*,
int *nss*,
char **beamflag*,

double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
char **comment*,
int **error*);

The function **mb_put_all** writes sonar data to the file listed in the **MBIO** descriptor pointed to by *MBIO_ptr*. The *verbose* value controls the standard error output verbosity of the function. A pointer to a data structure containing all of the data read is passed as *store_ptr*; the form of the data structure is determined by the sonar system associated with the format of the data being written. Additional data is passed if the data record is survey data (navigation, bathymetry, amplitude, and sidescan), navigation data (navigation only), or comment data (comment only). If the *usevalues* flag is set to 1, then the passed values will be inserted in the data structure pointed to by *store_ptr* before the data is written. If the *usevalues* flag is set to 0, the data structure pointed to by *store_ptr* will be written without modification. The values to be output are:

store_ptr: pointer to complete data structure
usevalues: flag controlling use of data passed by value

0	do not insert into data structure before writing the data
1	insert into data structure before writing the data

kind: kind of data record to be written

1	survey data
2	comment
3	header
4	calibrate
5	mean sound speed
6	SVP
7	standby
8	nav source
9	parameter
10	start
11	stop
12	nav
13	run parameter
14	clock
15	tide
16	height
17	heading
18	attitude
19	ssv
20	angle
21	event
22	history
23	summary
24	processing parameters
25	sensor parameters
26	navigation error
27	uninterpretable line

time_i: time of current ping (used if *time_i*[0] != 0)
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond
time_d: time of current ping in seconds since
1/1/70 00:00:00 (used if *time_i*[0] = 0)
navlon: longitude
navlat: latitude
speed: ship speed in km/s
heading: ship heading in degrees
nbath: number of bathymetry values
namp: number of amplitude values
nss: number of sidescan values
beamflag: array of bathymetry flags
bath: array of bathymetry values in meters
amp: array of amplitude values in unknown units
bathacrosstrack: array of of acrosstrack distances
in meters corresponding to bathymetry
bathalongtrack: array of of alongtrack distances
in meters corresponding to bathymetry
ss: array of sidescan values in unknown units
ssacrosstrack: array of of acrosstrack distances
in meters corresponding to sidescan
ssacrosstrack: array of of alongtrack distances
in meters corresponding to sidescan
comment: comment string

The return values are:
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about write failures.

---

int **mb_put_comment**(
int *verbose*,
char **mbio_ptr*,
char **comment*,
int **error*);

The function **mb_put_comment** writes a comment to the file listed in the **MBIO** descriptor pointed to by *MBIO_ptr*. The *verbose* value controls the standard error output verbosity of the function. The data is in the form of a null terminated string. The maximum length of comments varies with different data formats. In general individual comments should be less than 80 characters long to insure compatibility with all formats. The values to be output are:
comment: comment string

The return values are:
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about write failures.

```
------------------------------------------------------
int mb_extract(
                int verbose,
                char *mbio_ptr,
                char *store_ptr,
                int *kind,
                int time_i[7],
                double *time_d,
                double *navlon,
                double *navlat,
                double *speed,
                double *heading,
                int *nbath,
                int *namp,
                int *nss,
                char *beamflag,
                double *bath,
                double *amp,
                double *bathacrosstrack,
                double *bathalongtrack,
                double *ss,
                double *ssacrosstrack,
                double *ssalongtrack,
                char *comment,
                int *error);
```

The function **mb_extract** extracts sonar data from the structure pointed to by **store_ptr* according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is stored in **store_ptr*. Additional data is returned if the data record is survey data (navigation, bathymetry, amplitude, and sidescan), navigation data (navigation only), or comment data (comment only).

The return values are:

kind:	kind of data record read	
	1	survey data
	2	comment
	12	navigation
time_i:	time of current ping	
	time_i[0]: year	
	time_i[1]: month	
	time_i[2]: day	
	time_i[3]: hour	
	time_i[4]: minute	
	time_i[5]: second	
	time_i[6]: microsecond	
time_d:	time of current ping in seconds since 1/1/70 00:00:00	
navlon:	longitude	
navlat:	latitude	

speed:	ship speed in km/s
heading:	ship heading in degrees
distance:	distance along shiptrack since last ping in km
altitude:	altitude of sonar above seafloor in m
sonardepth:	depth of sonar in m
nbath:	number of bathymetry values
namp:	number of amplitude values
nss:	number of sidescan values
beamflag:	array of bathymetry flags
bath:	array of bathymetry values in meters
amp:	array of amplitude values in unknown units
bathacrosstrack:	array of of acrosstrack distances in meters corresponding to bathymetry
bathalongtrack:	array of of alongtrack distances in meters corresponding to bathymetry
ss:	array of sidescan values in unknown units
ssacrosstrack:	array of of acrosstrack distances in meters corresponding to sidescan
ssacrosstrack:	array of of alongtrack distances in meters corresponding to sidescan
comment:	comment string
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about extract failures.

---

int **mb_insert**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
int *kind*,
int *time_i[7]*,
double *time_d*,
double *navlon*,
double *navlat*,
double *speed*,
double *heading*,
int *nbath*,
int *namp*,
int *nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
char **comment*,
int **error*);

The function **mb_insert** inserts sonar data into the structure pointed to by **store_ptr* according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is to be stored in **store_ptr*. Data will be inserted only if the data record is survey data (navigation, bathymetry, amplitude, and sidescan), navigation data (navigation only), or comment data (comment only). The values to be inserted are:

kind: kind of data record inserted
- 1 survey data
- 2 comment
- 12 navigation

time_i: time of current ping
- *time_i*[0]: year
- *time_i*[1]: month
- *time_i*[2]: day
- *time_i*[3]: hour
- *time_i*[4]: minute
- *time_i*[5]: second
- *time_i*[6]: microsecond

time_d: time of current ping in seconds since 1/1/70 00:00:00

navlon: longitude

navlat: latitude

speed: ship speed in km/s

heading: ship heading in degrees

distance: distance along shiptrack since last ping in km

altitude: altitude of sonar above seafloor in m

sonardepth: depth of sonar in m

nbath: number of bathymetry values

namp: number of amplitude values

nss: number of sidescan values

beamflag: array of bathymetry flags

bath: array of bathymetry values in meters

amp: array of amplitude values in unknown units

bathacrosstrack: array of of acrosstrack distances in meters corresponding to bathymetry

bathalongtrack: array of of alongtrack distances in meters corresponding to bathymetry

ss: array of sidescan values in unknown units

ssacrosstrack: array of of acrosstrack distances in meters corresponding to sidescan

ssacrosstrack: array of of alongtrack distances in meters corresponding to sidescan

comment: comment string

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about insert failures.

---

int **mb_extract_nav**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
int **kind*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **draft*,
double **roll*,
double **pitch*,
double **heave*,
int **error*);

The function **mb_extract_nav** extracts navigation data from the structure pointed to by **store_ptr* according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is stored in **store_ptr*. Navigation data is returned if the data record is survey data (navigation, bathymetry, amplitude, and sidescan) or navigation data (navigation only).

The return values are:

kind:	kind of data record read
	1 survey data
	12 navigation
time_i:	time of current ping
	time_i[0]: year
	time_i[1]: month
	time_i[2]: day
	time_i[3]: hour
	time_i[4]: minute
	time_i[5]: second
	time_i[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
draft:	sonar depth in meters
roll:	sonar roll in degrees
pitch:	sonar pitch in degrees
heave:	sonar heave in meters

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about extract failures.

–----------

int **mb_insert_nav**(
int *verbose*,

char **mbio_ptr*,
char **store_ptr*,
int *time_i[7]*,
double *time_d*,
double *navlon*,
double *navlat*,
double *speed*,
double *heading*,
double *draft*,
double *roll*,
double *pitch*,
double *heave*,
int **error*);

The function **mb_insert_nav** inserts navigation data into the structure pointed to by **store_ptr* according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is to be stored in **store_ptr*. Data will be inserted only if the data record is survey data (navigation, bathymetry, amplitude, and sidescan), or navigation data (navigation only). The values to be inserted are:

time_i:	time of current ping
	time_i[0]: year
	time_i[1]: month
	time_i[2]: day
	time_i[3]: hour
	time_i[4]: minute
	time_i[5]: second
	time_i[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
draft:	sonar depth in meters
roll:	sonar roll in degrees
pitch:	sonar pitch in degrees
heave:	sonar heave in meters

The return values are:

error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about insert failures.

---

int **mb_extract_altitude**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
int **kind*,
double **transducer_depth*,
double **altitude*,

int **error*);

The function **mb_extract_altitude** extracts the sonar transducer depth (**transducer_depth**) below the sea surface and the the sonar transducer **altitude** above the seafloor according to the **MBIO** descriptor pointed to by *mbio_ptr*. This function is not defined for all data formats. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is stored in **store_ptr*. These data are returned only if the data record is survey data. These values are useful for sidescan processing applications. Both transducer depths and altitudes are reported in meters.

The return values are:

kind:	kind of data record read (error if not survey data): 1 survey data
transducer_depth:	depth of sonar in meters
altitude:	altitude of sonar above seafloor in meters.
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data extraction failures.

---

int **mb_insert_altitude**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
double *transducer_depth*,
double *altitude*,
int **error*);

The function **mb_insert_altitude** inserts sonar depth and altitude data into the structure pointed to by **store_ptr* according to the **MBIO** descriptor pointed to by *mbio_ptr*. This function is not defined for all data formats. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**. Data will be inserted only if the data record is survey data (navigation, bathymetry, amplitude, and sidescan). The values to be inserted are:

transducer_depth:	depth of sonar in meters
altitude:	altitude of sonar in meters

The return values are:

error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about insert failures.

---

int **mb_extract_svp**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
int **kind*,
int **nsvp*,

double **depth*,
double **velocity*,
int **error*);

The function **mb_extract_svp** extracts a water sound velocity profile according to the **MBIO** descriptor pointed to by *mbio_ptr*. This function is not defined for all data formats. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is stored in **store_ptr*. These data are returned only if the data record is a sound velocity profile record. These values are useful for calculating bathymetry from travel times and beam angles.

The return values are:

kind:	kind of data record read (error if not SVP data): 6 SVP data
nsvp:	number of depth and sound speed data in the profile
depth:	array of depths in meters
velocity:	array of sound speeds in m/sec
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data extraction failures.

---

int **mb_insert_svp**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
int *nsvp*,
double **depth*,
double **velocity*,
int **error*);

The function **mb_insert_svp** inserts a water sound velocity profile according to the **MBIO** descriptor pointed to by *mbio_ptr*. This function is not defined for all data formats. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**. These data are inserted only if the data record is a sound velocity profile record. These values are useful for calculating bathymetry from travel times and beam angles. The inserted values are:

nsvp:	number of depth and sound speed data in the profile
depth:	array of depths in meters
velocity:	array of sound speeds in m/sec

The return values are:

error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data insertion failures.

---

int **mb_ttimes**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
int **kind*,
int **nbeams*,
double **ttimes*,
double **angles*,
double **angles_forward*,
double **angles_null*,
double **heave*,
double **alongtrack_offset*,
double **draft*,
double **ssv*,
int **error*);

The function **mb_ttimes** extracts travel times and beam angles from a sonar-specific data structure pointed to by *store_ptr*. These values are used for calculating swath bathymetry. The *verbose* value controls the standard error output verbosity of the function. The coordinates of the beam angles can be a bit confusing. The angles are returned in "takeoff angle coordinates" appropriate for raytracing. The array angles contains the angle from vertical and the array angles_forward contains the angle from acrosstrack. This coordinate system is distinct from the roll-pitch coordinates appropriate for correcting roll and pitch values. A description of these relevent coordinate systems is given below. The **angles_null** array contains the effective sonar array orientation for each beam. The **angles_null** array may be used to correct beam angles using Snell's law if the **ssv** is changed. The **angles_null** values reflect the sonar configuration. For example, some multibeam sonars have a flat transducer array, and so the **angles_null** array consists of **nbeams** zero values. Other multibeams have circular arrays so that the **angles_null** values equal the **angles** values. The **alongtrack_offset** array accommodates sonars which report multiple pings in a single survey record; each ping occurs at a different position along the shiptrack, producing alongtrack offsets relative to the navigation for some beam values. The sum of the **draft** value and the **heave** array values gives the depth of the sonar for each beam. For hull mounted installations the **draft** value is generally static but the **heave** values vary with time. For towed sonars the **draft** varies with time and the **heave** values are typically zero. The **ssv** value gives the water sound velocity at the sonar array.

The return values are:

kind:	kind of data record read (error if not survey data): 1 survey data
nbeams:	number of beams
ttimes:	array of two-way travel times in seconds
angles:	array of angles from vertical in degrees
angles_forward:	array of angles from acrosstrack in degrees
angles_null:	array of sonar array orientation in degrees
heave:	array of heave values for each beam in meters
alongtrack_offset:	array of alongtrack distance offsets for each beam in meters
draft:	draft of sonar in meters
ssv:	water sound velocity at sonar in m/seconds
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data extraction failures.

---

int **mb_detects**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int **nbeams*,
int **detects*,
int **error*);

The function **mb_detects** extracts beam bottom detect types from a sonar-specific data structure pointed to by *store_ptr*. These values indicate whether the depth value associated with a particular beam i derived from an amplitude detect (e.g. detects[i] = 1), a phase detect (e.g. detects[i] = 2), or the algorithm is unknown (e.g. detects[i] = 0). The *verbose* value controls the standard error output verbosity of the function.

The return values are:

kind:	kind of data record read (error if not survey data): 1 survey data
nbeams:	number of beams
detects:	array of *nbeams* bottom detect algorithm flags 0 = unknown 1 = amplitude detect 2 = phase detect
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data extraction failures. This functionality is available for only a subset of the supported sonars. If the corresponding low level routine is undefined, **error* will be set to MB_ERROR_BAD_SYSTEM (14).

---

int **mb_gains**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
double **transmit_gain*,
double **pulse_length*,
double **receive_gain*,
int **error*);

The function **mb_gains** extracts the most basic gain settings from a sonar-specific data structure pointed to by *store_ptr*. In many cases, sonars have more complicated gain functions, particularly with respect to the receiver TVG function. In those cases, the receive gain returned here refers to the constant gain setting and does not include any TVG parameters. The *verbose* value controls the standard error output verbosity of the function.

The return values are:

kind:	kind of data record read (error if not survey data): 1 survey data
transmit_gain:	transmit gain (dB)
pulse_length:	transmit pulse length (sec)
receive_gain:	receive gain (dB)

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data extraction failures. This functionality is available for only a subset of the supported sonars. If the corresponding low level routine is undefined, **error* will be set to MB_ERROR_BAD_SYSTEM (14).

---

int **mb_extract_rawss**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
int **kind*,
int **nrawss*,
double **rawss*,
double **rawssacrosstrack*,
double **rawssalongtrack*,
int **error*);

This function has not yet been implemented for any data format. The notion is that since some formats carry both "raw" and "processed" sidescan imagery, there should be functions to extract and insert the "raw" sidescan. Given that the meaning of "raw" sidescan varies greatly among sonars, the processing one might apply to the data will depend on the sonar source. The definition of **mb_extract_rawss** may well change when we actually implement it.

---

int **mb_insert_rawss**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
int *nrawss*,
double **rawss*,
double **rawssacrosstrack*,
double **rawssalongtrack*,
int **error*);

This function has not yet been implemented for any data format. The notion is that since some formats carry both "raw" and "processed" sidescan imagery, there should be functions to extract and insert the "raw" sidescan. Given that the meaning of "raw" sidescan varies greatly among sonars, the processing one might apply to the data will depend on the sonar source. The definition of **mb_insert_rawss** may well change when we actually implement it.

---

int **mb_copyrecord**(
int *verbose*,
char **mbio_ptr*,
char **store_ptr*,
char **copy_ptr*,
int **error*);

The function **mb_copyrecord** copies the sonar-specific data structure pointed to by *store_ptr* into the data structure pointed to by **copy_ptr*. The data structures must already have been allocated.

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data copy failures.

LEVEL 3 FUNCTIONS

int **mb_buffer_init**(
int *verbose*,
char **buff_ptr*,
int **error*);

The function **mb_buffer_init** initializes the data structures required for buffered i/0. A pointer to the buffer data structure is returned as **buff_ptr*. The *verbose* value controls the standard error output verbosity of the function.

The return values are:
**buff_ptr*: pointer to buffer structure
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer initialization failures.

---

int **mb_buffer_close**(
int *verbose*,
char **buff_ptr*,
char **mbio_ptr*,
int **error*);

The function **mb_buffer_close** releases all memory allocated for buffered i/0, including the structure pointed to by **buff_ptr*. The *verbose* value controls the standard error output verbosity of the function.

The return values are:
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer deallocation failures.

---

int **mb_buffer_load**(
int *verbose*,
char **buff_ptr*,char **mbio_ptr*,
int *nwant*,
int **nload*,
int **nbuff*,
int **error*);

The function **mb_buffer_load** loads data into the buffer pointed to by *buff_ptr* from the input file initialized in the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:
nwant: The number of data records desired
in the buffer.

The returned values are:

nload:	The number of data records loaded into the buffer.
nbuff:	The total number of data records in the buffer after loading.
error:	error value

The buffer may already contain data records when the **mb_buffer_load** call is made; if the number of previously loaded records is less than *nwant*, the function will attempt to read and load records until a total of *nwant* records are loaded. The *nload* value is the number of data records loaded during the current function call, and the *nbuff* value is the number of data records in the buffer at the completion of the **mb_buffer_load** call. A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer deallocation failures.

---

int **mb_buffer_dump**(
int *verbose*,
char **buff_ptr*,
char **mbio_ptr*,
char **ombio_ptr*,
int *nhold*,
int **ndump*,
int **nbuff*,
int **error*);

The function **mb_buffer_dump** dumps data from the buffer pointed to by **buff_ptr* into the output file initialized in the **MBIO** descriptor pointed to by *ombio_ptr*. The data in the buffer were read from the input file initialized in the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

nhold:	The number of data records desired to be held in the buffer.

The returned values are:

nload:	The number of data records dumped from the buffer.
nbuff:	The total number of data records in the buffer after dumping.
error:	error value

If the number of loaded records is more than *nhold*, the function will attempt to write out records from the beginning of the buffer until *nhold* records are left in the buffer. The *ndump* value is the number of data records dumped during the current function call, and the *nbuff* value is the number of data records in the buffer at the completion of the **mb_buffer_dump** call. A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer deallocation failures.

---

int **mb_buffer_clear**(
int *verbose*,
char **buff_ptr*,
char **mbio_ptr*,
int *nhold*,
int **ndump*,
int **nbuff*,
int **error*);

The function **mb_buffer_clear** removes data from the buffer pointed to by **buff_ptr* without writing those data records to an output file. An **MBIO** descriptor pointed to by *mbio_ptr* is still required, and generally represents the **MBIO** descriptor used to read and load the data originally. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

nwant: The number of data records desired to be held in the buffer.

The returned values are:

nload: The number of data records cleared from the buffer.
nbuff: The total number of data records in the buffer after dumping.
error: error value

If the number of loaded records is more than *nhold*, the function will attempt to clear out records from the beginning of the buffer until *nhold* records are left in the buffer. The *ndump* value is the number of data records cleared during the current function call, and the *nbuff* value is the number of data records in the buffer at the completion of the **mb_buffer_dump** call. A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer deallocation failures.

---

int **mb_buffer_info**(
int *verbose*,
char **buff_ptr*,
char **mbio_ptr*,
int *id*,
int **system*,
int **kind*,
int **error*);

The function **mb_buffer_clear** removes data from the buffer pointed to by **buff_ptr* without writing those data records to an output file. An **MBIO** descriptor pointed to by *mbio_ptr* is still required, and generally represents the **MBIO** descriptor used to read and load the data originally. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

nwant: The number of data records desired to be held in the buffer.

The returned values are:

nload: The number of data records cleared from the buffer.
nbuff: The total number of data records in the buffer after dumping.
error: error value

If the number of loaded records is more than *nhold*, the function will attempt to clear out records from the beginning of the buffer until *nhold* records are left in the buffer. The *ndump* value is the number of data records cleared during the current function call, and the *nbuff* value is the number of data records in the buffer at the completion of the **mb_buffer_dump** call. A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer deallocation failures.

---

int **mb_buffer_get_next_data**(
int *verbose*,
char **buff_ptr*,

char **mbio_ptr*,
int *start*,
int **id*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
int **nbath*,
int **namp*,
int **nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
int **error*);

The function **mb_buffer_get_next_data** searches for the next survey data record in the buffer, beginning at buffer index *start*. Since buffer indexes begin at 0, the first call to **mb_buffer_get_next_data** should have *start* = 0. If a survey data record is found at or beyond *start*, **mb_buffer_get_next_data** returns the buffer index of that record in *id*. Data is also returned in the forms of bathymetry, amplitude, and sidescan survey data. No comments or other non-survey data records are returned. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

start: The buffer index at which to start searching for a survey data record.

The returned values are:

id: The buffer index of the first survey data record at or after *start*.
time_i: time of current ping
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond
time_d: time of current ping in seconds since 1/1/70 00:00:00
navlon: longitude
navlat: latitude
speed: ship speed in km/s
heading: ship heading in degrees
nbath: number of bathymetry values
namp: number of amplitude values
nss: number of sidescan values
beamflag: array of bathymetry flags

bath:	array of bathymetry values in meters
amp:	array of amplitude values in unknown units
bathacrosstrack:	array of of acrosstrack distances in meters corresponding to bathymetry
bathalongtrack:	array of of alongtrack distances in meters corresponding to bathymetry
ss:	array of sidescan values in unknown units
ssacrosstrack:	array of of acrosstrack distances in meters corresponding to sidescan
ssacrosstrack:	array of of alongtrack distances in meters corresponding to sidescan
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures. The most common error occurs when no more survey data records remain to be found in the buffer; in this case, *error* = −14.

```
------------------------------------------------------
int mb_buffer_extract(
                int verbose,
                char *buff_ptr,
                char *mbio_ptr,
                int id,
                int *kind,
                int time_i[7],
                double *time_d,
                double *navlon,
                double *navlat,
                double *speed,
                double *heading,
                int *nbath,
                int *namp,
                int *nss,
                char *beamflag,
                double *bath,
                double *amp,
                double *bathacrosstrack,
                double *bathalongtrack,
                double *ss,
                double *ssacrosstrack,
                double *ssalongtrack,
                char *comment,
                int *error);
```

The function **mb_buffer_extract** extracts and returns a subset of the data in a buffer record. The *verbose* value controls the standard error output verbosity of the function. The buffer record is specified with the buffer index *id*. The data is either in the form of bathymetry, amplitude, and sidescan survey data or a comment string.

The input control parameters have the following significance:

id:	The buffer index of the data record to extract.

The returned values are:

kind: kind of data record extracted
- 1 survey data
- 2 comment
- >=3 other data that cannot be passed by **mb_buffer_extract**

time_i: time of current ping
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond

time_d: time of current ping in seconds since 1/1/70 00:00:00

navlon: longitude

navlat: latitude

speed: ship speed in km/s

heading: ship heading in degrees

nbath: number of bathymetry values

namp: number of amplitude values

nss: number of sidescan values

beamflag: array of bathymetry flags

bath: array of bathymetry values in meters

amp: array of amplitude values in unknown units

bathacrosstrack: array of of acrosstrack distances in meters corresponding to bathymetry

bathalongtrack: array of of alongtrack distances in meters corresponding to bathymetry

ss: array of sidescan values in unknown units

ssacrosstrack: array of of acrosstrack distances in meters corresponding to sidescan

ssacrosstrack: array of of alongtrack distances in meters corresponding to sidescan

comment: comment string

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about extract failures.

---

int **mb_buffer_insert**(
int *verbose*,
char **buff_ptr*,
char **mbio_ptr*,
int *id*,
int *time_i[7]*,
double *time_d*,
double *navlon*,
double *navlat*,
double *speed*,
double *heading*,
int *nbath*,
int *namp*,

int *nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
char **comment*,
int **error*);

The function **mb_buffer_insert** inserts data into a buffer record, replacing a subset of the original values. The *verbose* value controls the standard error output verbosity of the function. The buffer record is specified with the buffer index *id*. The data is either in the form of bathymetry, amplitude, and sidescan survey data or a comment string.

The input control parameters have the following significance:

id: The buffer index of the data record to insert.

The returned values are:

kind: kind of data record inserted

1	survey data
2	comment
>=3	other data that cannot be passed by **mb_buffer_insert**

time_i: time of current ping
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond

time_d: time of current ping in seconds since 1/1/70 00:00:00

navlon: longitude

navlat: latitude

speed: ship speed in km/s

heading: ship heading in degrees

nbath: number of bathymetry values

namp: number of amplitude values

nss: number of sidescan values

beamflag: array of bathymetry flags

bath: array of bathymetry values in meters

amp: array of amplitude values in unknown units

bathacrosstrack: array of of acrosstrack distances in meters corresponding to bathymetry

bathalongtrack: array of of alongtrack distances in meters corresponding to bathymetry

ss: array of sidescan values in unknown units

ssacrosstrack: array of of acrosstrack distances in meters corresponding to sidescan

ssacrosstrack: array of of alongtrack distances
in meters corresponding to sidescan
comment: comment string

The returned values are:
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about insert failures.

---

int **mb_buffer_get_next_nav**(
int *verbose*,
char **buff_ptr*,
char **mbio_ptr*,
int *start*,
int **id*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **draft*,
double **roll*,
double **pitch*,
double **heave*,
int **error*);

The function **mb_buffer_get_next_nav** searches for the next survey data record in the buffer, beginning at buffer index *start*. Since buffer indexes begin at 0, the first call to **mb_buffer_get_next_nav** should have *start* = 0. If a survey data record is found at or beyond *start*, **mb_buffer_get_next_nav** returns the buffer index of that record in *id*. Navigation and vertical reference sensor data is also returned. No comments or other non-survey data records are returned. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:
start: The buffer index at which to start
searching for a survey data record.

The returned values are:
id: The buffer index of the first survey data record at or after *start*.
time_i: time of current ping
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond
time_d: time of current ping in seconds
since 1/1/70 00:00:00
navlon: longitude
navlat: latitude

speed: ship speed in km/s
heading: ship heading in degrees
roll: ship roll in degrees
pitch: ship pitch in degrees
heave: ship heave in meters

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures. The most common error occurs when no more survey data records remain to be found in the buffer; in this case, *error* = −14.

```
------------------------------------------------------
int mb_buffer_extract_nav(
                int verbose,
                char *buff_ptr,
                char *mbio_ptr,
                int id,
                int *kind,
                int time_i[7],
                double *time_d,
                double *navlon,
                double *navlat,
                double *speed,
                double *heading,
                double *draft,
                double *roll,
                double *pitch,
                double *heave,
                int *error);
```

The function **mb_buffer_extract_nav** extracts and returns a subset of the data in a buffer record. The *verbose* value controls the standard error output verbosity of the function. The buffer record is specified with the buffer index *id*. The data returned consists of navigation and vertical reference sensor data.

The input control parameters have the following significance:

id: The buffer index of the data record to extract.

The returned values are:

kind: kind of data record extracted
- 1 survey data
- 2 comment
- >=3 other data that cannot be passed by **mb_buffer_extract_nav**

time_i: time of current ping
- *time_i*[0]: year
- *time_i*[1]: month
- *time_i*[2]: day
- *time_i*[3]: hour
- *time_i*[4]: minute
- *time_i*[5]: second
- *time_i*[6]: microsecond

time_d: time of current ping in seconds since 1/1/70 00:00:00

navlon: longitude

navlat: latitude
speed: ship speed in km/s
heading: ship heading in degrees
roll: ship roll in degrees
pitch: ship pitch in degrees
heave: ship heave in meters

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about extract failures.

---

int **mb_buffer_insert_nav**(
int *verbose*,
char **buff_ptr*,
char **mbio_ptr*,
int *id*,
int *time_i[7]*,
double *time_d*,
double *navlon*,
double *navlat*,
double *speed*,
double *heading*,
double *draft*,
double *roll*,
double *pitch*,
double *heave*,
int **error*);

The function **mb_buffer_insert_nav** inserts navigation and vertical reference sensor data into a buffer record, replacing a subset of the original values. The *verbose* value controls the standard error output verbosity of the function. The buffer record is specified with the buffer index *id*.

The input control parameters have the following significance:

id: The buffer index of the data record to insert.

The returned values are:

kind: kind of data record inserted
1 survey data
2 comment
>=3 other data that cannot be passed by **mb_buffer_insert_nav**
time_i: time of current ping
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond
time_d: time of current ping in seconds since 1/1/70 00:00:00
navlon: longitude
navlat: latitude

speed: ship speed in km/s
heading: ship heading in degrees
roll: ship roll in degrees
pitch: ship pitch in degrees
heave: ship heave in meters

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about insert failures.

---

int **mb_buffer_get_ptr**(
int *verbose*,
char **buff_ptr*,
char **mbio_ptr*,
int *id*,
char ***store_ptr*,
int **error*);

The function **mb_buffer_get_ptr** returns a pointer to the data structure in a buffer record. The *verbose* value controls the standard error output verbosity of the function. The buffer record is specified with the buffer index *id*. The data returned consists of a pointer to the data structure stored in the specified buffer record.

The input control parameters have the following significance:
id: The buffer index of the data record to locate.

The return values are:
**store_ptr*: pointer to data in specified buffer record
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer failures.

MISCELLANEOUS FUNCTIONS

int **mb_defaults**(
int *verbose*,
int **format*,
int **pings*,
int **lonflip*,
double *bounds[4]*,
int **btime_i*,
int **etime_i*,
double **speedmin*,
double **timegap*);

The function **mb_defaults** provides default values of control parameters used by some of the **MBIO** functions. The *verbose* value controls the standard error output verbosity of the function. The other parameters are set by the function; the meaning of these parameters is discussed in the listings of the functions **mb_read_init** and **mb_write_init**. If an .mbio_defaults file exists in the user's home directory, the lonflip and timegap defaults are read from this file. Otherwise, the values are set as:
**lonflip* = 0
**timegap* = 1

The other values are simply set as:

**format* = 0
**pings* = 1
bounds[0] = −360.
bounds[1] = 360.
bounds[2] = −90.
bounds[3] = 90.
btime_i[0] = 1962;
btime_i[1] = 2;
btime_i[2] = 21;
btime_i[3] = 10;
btime_i[4] = 30;
btime_i[5] = 0;
btime_i[6] = 0;
etime_i[0] = 2062;
etime_i[1] = 2;
etime_i[2] = 21;
etime_i[3] = 10;
etime_i[4] = 30;
etime_i[5] = 0;
etime_i[6] = 0;
**speedmin* = 0.0

A status value is returned to indicate success or failure.

---

int **mb_env**(
int *verbose*,
char **psdisplay*,
char **imgdisplay*,
char **mbproject*);

The function **mb_env** provides default values of Postscript and image display programs invoked by some **MB-System** programs and macros, and a default value for a working project name that will be used by future applications. The *verbose* value controls the standard error output verbosity of the function. If an .mbio_defaults file exists in the user's home directory, the **psdisplay*, **imgdisplay*, **mbproject* defaults are read from this file. Otherwise, the values are set as:

psdisplay = "xpsview" (IRIX OS)
"pageview" (Solaris OS)
"gv" (other OS)
"ghostview" (other OS)
imgdisplay = "gimp" (Linux OS)
"xv" (other than Linux OS)
mbproject = "none"

---

int **mb_format**(
int *verbose*,
int **format*,
int **error*);

Given the format identifier *format*, **mb_format** checks if the format is valid. If the format id corresponds to a value used in previous (<4.00) versions of **MB-System**, then the format value will be aliased to the current corresponding value.

The return values are:

format:	**MBIO** format id
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_format_register**(
int *verbose*,
int **format*,
char **mbio_ptr*,
int **error*);

The function **mb_format_register** is called by **mb_read_init** and **mb_write_init** and serves to load format specific parameters and function parameters into the **MBIO** control structure pointed to by **error*. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values.

The input values are:

**format*:	**MBIO** format id
**mbio_ptr*:	pointer to data in specified buffer record

The return values are:

error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_format_info**(
int *verbose*,
int **format*,
int **system*,
int **beams_bath_max*,
int **beams_amp_max*,
int **pixels_ss_max*,
char **format_name*,
char **system_name*,
char **format_description*,
int **numfile*,
int **filetype*,
int **variable_beams*,
int **traveltime*,
int **beam_flagging*,
int **nav_source*,
int **heading_source*,
int **vru_source*,
double **beamwidth_xtrack*,
double **beamwidth_ltrack*,
int **error*);

The function **mb_format_info** returns a variety of data format specific parameters. The format id **format*

is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values.

The input values are:

format*: **MBIO format id

The return values are:

format*: **MBIO format id
system*: **MBIO sonar system id
**beams_bath_max*: maximum number of bathymetry beams
**beams_amp_max*: maximum number of amplitude beams
**pixels_ss_max*: maximum number of sidescan pixels
format_name*: **MBIO format name
system_name*: **MBIO sonar system name
format_description*: **MBIO format description
**numfile*: number of parallel data files used in format
**filetype*: type of data files
**variable_beams*: number of beams can vary [boolean]
**traveltime*: travel time data available [boolean]
**beam_flagging*: beam flagging supported [boolean]
**nav_source*: kind of data records containing navigation
**heading_source*: kind of data records containing heading
**vru_source*: kind of data records containing attitude
**beamwidth_xtrack*: typical athwartships beam width [degrees]
**beamwidth_ltrack*: typical alongtrack beam width [degrees]
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_format_system**(
int *verbose*,
int **format*,
int **system*,
int **error*);

The function **mb_format_system** returns the **MBIO** sonar system id. The format id **format* is first checked for validity. In some cases, formerly valid but now oattintbsolete format id values are mapped to current values. The input values are:

format*: **MBIO format id

The return values are:

format*: **MBIO format id
system*: **MBIO sonar system id
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_format_description**(

int *verbose*,
int **format*,
char **description*,
int **error*);

The function **mb_format_description** returns a short description of the format in the string **description*. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values. The input values are:

format: **MBIO** format id

The return values are:

format: **MBIO** format id
format_description: **MBIO** format description
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_format_dimensions**(
int *verbose*,
int **format*,
int **beams_bath_max*,
int **beams_amp_max*,
int **pixels_ss_max*,
int **error*);

The function **mb_format_dimensions** returns the maximum numbers of beams and pixels associated with a particular data format. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values. The input values are:

format: **MBIO** format id

The return values are:

format: **MBIO** format id
beams_bath_max: maximum number of bathymetry beams
beams_amp_max: maximum number of amplitude beams
pixels_ss_max: maximum number of sidescan pixels
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_format_flags**(
int *verbose*,
int **format*,
int **variable_beams*,
int **traveltime*,
int **beam_flagging*,
int **error*);

The function **mb_format_flags** returns flags indicating certain characteristics of the specified data format. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values. The input values are:

format: **MBIO** format id

The return values are:

format: **MBIO** format id
variable_beams:number of beams can vary [boolean]

**traveltime*: travel time data available [boolean]
**beam_flagging*: beam flagging supported [boolean]
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_format_source**(
int *verbose*,
int **format*,
int **nav_source*,
int **heading_source*,
int **vru_source*,
int **error*);

The function **mb_format_source** returns flags indicating what kinds of data records contain navigation, heading, and attitude values in the specified data format. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values. The input values are:

format*: **MBIO format id

The return values are:

format*: **MBIO format id
**nav_source*: kind of data records containing navigation
**heading_source*: kind of data records containing heading
**vru_source*: kind of data records containing attitude
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_format_beamwidth**(
int *verbose*,
int **format*,
double **beamwidth_xtrack*,
double **beamwidth_ltrack*,
int **error*);

The function **mb_format_beamwidth** returns typical, upper bound values for athwartships and alongtrack beam widths. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values. The input values are:

format*: **MBIO format id

The return values are:

format*: **MBIO format id
**beamwidth_xtrack*: typical athwartships beam width [degrees]
**beamwidth_ltrack*: typical alongtrack beam width [degrees]
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_datalist_open**(
int *verbose*,
char ***datalist*,
char **path*,
int *look_processed*,
int **error*);

The function **mb_datalist_open** initializes reading from a datalist tree. The string **path* is the path to the top level datalist file to be opened. The value *look_processed* indicates whether the datalist parsing should look for or ignore processed data files (see the **mbprocess** and **mbdatalist** manual pages). The input values are:

path: datalist file to be opened
look_processed: processed file behavior
0 : unset
1 : ignore processed files
2 : return processed files

The return values are:

**datalist*: pointer to datalist structure
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_datalist_read**(
int *verbose*,
char **datalist*,
char **path*,
int **format*,
double **weight*,
int **error*);

The function **mb_datalist_read** reads from a datalist tree, attempting to return the path to the next valid swath data file, the corresponding data format id, and a gridding weight (see the **mbprocess** and **mbdatalist** manual pages). Information about the datalist tree is embedded in a data structure pointed to by **datalist*. The input values are:

datalist: pointer to datalist structure

The return values are:

path: swath data file
format: **MBIO** format id
weight: **mbgrid** gridding weight
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_datalist_close**(
int *verbose*,
char ***datalist*,
int **error*);

The function **mb_datalist_close** closes an open datalist tree, and deallocates the data structure pointed to

by **datalist*. The input values are:

**datalist*: pointer to datalist structure

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_alloc**(
int *verbose*,
char **mbio_ptr*,
char ***store_ptr*,
int **error*);

The function **mb_alloc** allocates a data structure for internal storage of swath sonar data and returns a pointer to this structure in **store_ptr*. The data structure is specific to the data format identified in the **MBIO** data structure pointed to by **mbio_ptr*. The input values are:

mbio_ptr*: pointer to **MBIO structure

The return values are:

***store_ptr*: pointer to storage data structure

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_deall**(
int *verbose*,
char **mbio_ptr*,
char ***store_ptr*,
int **error*);

The function **mb_deall** deallocates a format specific swath sonar data structure pointed to by **store_ptr*. The input values are:

mbio_ptr*: pointer to **MBIO structure

**store_ptr*: pointer to storage data structure

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_error**(
int *error*,
int *error*,
char ***message*);

Given the error value *error*, **mb_format_inf** returns a short error message in the string ***message*. The *verbose* value controls the standard error output verbosity of the function. The return status value signals success if *format* is valid and failure otherwise.

---

int **mb_navint_add**(
int *verbose*,
char **mbio_ptr*,
double *time_d*,
double *lon*,
double *lat*,
int **error*);

The function **mb_navint_add** adds a navigation fix to a circular buffer of navigation values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate navigation for data formats where the navigation is asynchronous (where navigation and survey pings come in different data records). The input values are:

mbio_ptr: pointer to **MBIO** structure
time_d: time of navigation fix in seconds since 1/1/70 00:00:00
lon: longitude (degrees)
lat: latitude (degrees)

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_navint_interp**(
int *verbose*,
char **mbio_ptr*,
double *time_d*,
double *heading*,
double *rawspeed*,
double **lon*,
double **lat*,
double **speed*,
int **error*);

The function **mb_navint_interp** interpolates navigation to the time *time_d* using a circular buffer of navigation values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate navigation for data formats where the navigation is asynchronous (where navigation and survey pings come in different data records). The input values are:

mbio_ptr: pointer to **MBIO** structure
time_d: time of current ping in seconds since 1/1/70 00:00:00
heading: heading in degrees
rawspeed: speed in km/hr (zero if not known)

The return values are:

**lon*: longitude (degrees)
**lat*: latitude (degrees)
**speed*: speed made good in km/hr
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_attint_add**(

int *verbose*,
char **mbio_ptr*,
double *time_d*,
double *heave*,
double *roll*,
double *pitch*,
int **error*);

The function **mb_attint_add** adds an attitude (heave, roll, pitch) data point to a circular buffer of attitude values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate attitude for data formats where the attitude is asynchronous (where attitude and survey pings come in different data records). The input values are:

mbio_ptr*: pointer to **MBIO structure
time_d: time of attitude in seconds since 1/1/70 00:00:00
heave: heave (meters, up +)
roll: roll (degrees, starboard up +)
pitch: pitch (degrees, forward up +)

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_attint_interp**(
int *verbose*,
char **mbio_ptr*,
double *time_d*,
double **heave*,
double **roll*,
double **pitch*,
int **error*);

The function **mb_attint_interp** interpolates attitude (heave, roll, pitch) data to the time *time_d* using a circular buffer of attitude values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate attitude for data formats where the attitude is asynchronous (where attitude and survey pings come in different data records). The input values are:

mbio_ptr*: pointer to **MBIO structure
time_d: time of current ping in seconds since 1/1/70 00:00:00

The return values are:

**heave*: heave (meters, up +)
**roll*: roll (degrees, starboard up +)
**pitch*: pitch (degrees, forward up +)
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_hedint_add**(
int *verbose*,
char **mbio_ptr*,
double *time_d*,
double *heading*,

int *error);

The function **mb_hedint_add** adds a heading point to a circular buffer of heading values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate heading for data formats where the heading is asynchronous (where heading and survey pings come in different data records). The input values are:

mbio_ptr: pointer to **MBIO** structure
time_d: time of heading value in seconds since 1/1/70 00:00:00
heading: heading (degrees)

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_hedint_interp**(
int *verbose*,
char **mbio_ptr*,
double *time_d*,
double **heading*,
int **error*);

The function **mb_hedint_interp** interpolates heading to the time *time_d* using a circular buffer of heading values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate heading for data formats where the heading is asynchronous (where heading and survey pings come in different data records). The input values are:

mbio_ptr: pointer to **MBIO** structure
time_d: time of current ping in seconds since 1/1/70 00:00:00

The return values are:

heading: heading in degrees
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

---

int **mb_get_double**(
double **value*,
char **str*,
int *nchar*);

The function **mb_get_double** parses the first *nchar* characters of the string **str* for a floating point value, storing this value as a double in **value*.

---

int **mb_get_int**(
int **value*,
char **str*,
int *nchar*);

The function **mb_get_int** parses the first *nchar* characters of the string **str* for an integer value, storing this value as a int in **value*.

---

int **mb_get_binary_short**(
int *swapped*,
void **buffer*,
short **value*);

The function **mb_get_binary_short** extracts a short int value from the first two bytes pointed to by **buffer*. If the boolean *swapped* is true, the byte order of **value* is swapped.

---

int **mb_get_binary_int**(
int *swapped*,
void **buffer*,
int **value*);

The function **mb_get_binary_int** extracts an int value from the first four bytes pointed to by **buffer*. If the boolean *swapped* is true, the byte order of **value* is swapped.

---

int **mb_get_binary_float**(
int *swapped*,
void **buffer*,
float *value*);

The function **mb_get_binary_float** *extracts a float value from the first four bytes pointed to by *buffer. If the boolean swapped is true, the byte order of *value is swapped.*

---

int **mb_get_binary_double**(
int swapped,
*void *buffer,*
*double *value);*

The function **mb_get_binary_double** *extracts a double value from the first eight bytes pointed to by *buffer. If the boolean swapped is true, the byte order of *value is swapped.*

---

int **mb_put_binary_short**(
int swapped,
short value,
*void *buffer);*

The function **mb_put_binary_short** *inserts a short int value into the first two bytes pointed to by *buffer. If the boolean swapped is true, the byte order of value is swapped.*

---

int **mb_put_binary_int**(
int swapped,
int value,
*void *buffer);*

The function **mb_put_binary_int** *inserts an int value into the first four bytes pointed to by *buffer. If the boolean swapped is true, the byte order of value is swapped.*

---

int **mb_put_binary_float***(*
int swapped,
float value,
*void *buffer);*

The function **mb_put_binary_float** *inserts a float value into the first four bytes pointed to by *buffer. If the boolean swapped is true, the byte order of value is swapped.*

---

int **mb_put_binary_double***(*
int swapped,
double value,
*void *buffer);*

The function **mb_put_binary_double** *inserts a double value into the first eight bytes pointed to by *buffer. If the boolean swapped is true, the byte order of value is swapped.*

---

int **mb_get_bounds***(*
*char *text,*
*double *bounds);*

The function **mb_get_bounds** *parses the string *text and extracts geographic bounds of a rectangular region in the form:*
bounds[0]: minimum longitude
bounds[1]: maximum longitude
bounds[2]: minimum latitude
bounds[3]: maximum latitude
*where *text is in the standard* **GMT** *bounds form. The longitude and latitude values in *text should separated by a '/' character, and individual values may be represented in decimal degrees or in "dd:mm:ss" form (dd=degrees, mm=minutes, ss=seconds).*

double **mb_ddmmss_to_degree***(*
*char *text);*

The function **mb_ddmmss_to_degree** *parses the string *text and extracts a decimal longitude or latitude value from a "dd:mm:ss" (dd=degrees, mm=minutes, ss=seconds) value.*

---

int **mb_takeoff_to_rollpitch***(*
int verbose,
double theta,
double phi,
*double *alpha,*
*double *beta,*
*int *error);*

The function **mb_takeoff_to_rollpitch** *translates angles from the "takeoff" coordinate reference frame to the "rollpitch" coordinate system. See the discussion of coordinate systems below.*

---

int **mb_rollpitch_to_takeoff***(*
int verbose,

double alpha,
double beta,
*double *theta,*
*double *phi,*
*int *error);*

The function **mb_rollpitch_to_takeoff** *translates angles from the "rollpitch" coordinate reference frame to the "takeoff" coordinate system. See the discussion of coordinate systems below.*

---
int **mb_double_compare***(double *a,*
*double *b);*

The function **mb_double_compare** *is used with the* **qsort** *function. This function returns 1 if a > b and −1 if a <= b.*

---
int **mb_int_compare***(*
*int *a,*
*int *b);*

The function **mb_int_compare** *is used with the* **qsort** *function. This function returns 1 if a > b and −1 if a <= b.*

COORDINATE SYSTEMS USED IN MB-SYSTEM

I. Introduction

The coordinate systems described below are used within **MB-System** for calculations involving the location in space of depth, amplitude, or sidescan data. In all cases the origin of the coordinate system is at the center of the sonar transducers.

II. Cartesian Coordinates

The cartesian coordinate system used in **MB-System** is a bit odd because it is left-handed, as opposed to the right-handed x-y-z space conventionally used in most circumstances. With respect to the sonar (or the ship on which the sonar is mounted), the x-axis is athwartships with positive to starboard (to the right if facing forward), the y-axis is fore-aft with positive forward, and the z-axis is positive down.

III. Spherical Coordinates

There are two non-traditional spherical coordinate systems used in **MB-System**. The first, referred to here as takeoff angle coordinates, is useful for raytracing. The second, referred to here as roll-pitch coordinates, is useful for taking account of corrections to roll and pitch angles.

III.1. Takeoff Angle Coordinates

The three parameters are r, theta, and phi, where r is the distance from the origin, theta is the angle from vertical down (that is, from the positive z-axis), and phi is the angle from acrosstrack (the positive x-axis) in the x-y plane. Note that theta is always positive; the direction in the x-y plane is given by phi. Raytracing is simple in these coordinates because the ray takeoff angle is just theta. However, applying roll or pitch corrections is complicated because roll and pitch have components in both theta and phi.

0 <= theta <= PI/2
-PI/2 <= phi <= 3*PI/2

x = rSIN(theta)COS(phi)
y = rSIN(theta)SIN(phi)

z = rCOS(theta)

theta = 0 −--> vertical, along positive z-axis
theta = PI/2 −--> horizontal, in x-y plane
phi = −PI/2 −--> aft, in y-z plane with y negative
phi = 0 −--> port, in x-z plane with x positive
phi = PI/2 −--> forward, in y-z plane with y positive
phi = PI −--> starboard, in x-z plane with x negative
phi = 3*PI/2 −--> aft, in y-z plane with y negative

III.2. Roll-Pitch Coordinates

The three parameters are r, alpha, and beta, where r is the distance from the origin, alpha is the angle forward (effectively pitch angle), and beta is the angle from horizontal in the x-z plane (effectively roll angle). Applying a roll or pitch correction is simple in these coordinates because pitch is just alpha and roll is just beta. However, raytracing is complicated because deflection from vertical has components in both alpha and beta.

-PI/2 <= alpha <= PI/2
0 <= beta <= PI

x = rCOS(alpha)COS(beta)
y = rSIN(alpha)
z = rCOS(alpha)SIN(beta)

alpha = −PI/2 −--> horizontal, in x-y plane with y negative
alpha = 0 −--> ship level, zero pitch, in x-z plane
alpha = PI/2 −--> horizontal, in x-y plane with y positive
beta = 0 −--> starboard, along positive x-axis
beta = PI/2 −--> in y-z plane rotated by alpha
beta = PI −--> port, along negative x-axis

IV. SeaBeam Coordinates

The per-beam parameters in the SB2100 data format include angle-from-vertical and angle-forward. Angle-from-vertical is the same as theta except that it is signed based on the acrosstrack direction (positive to starboard, negative to port). The angle-forward values are also defined slightly differently from phi, in that angle-forward is signed differently on the port and starboard sides. The SeaBeam 2100 External Interface Specifications document includes both discussion and figures illustrating the angle-forward value. To summarize:

Port:

theta = absolute value of angle-from-vertical

-PI/2 <= phi <= PI/2
is equivalent to
-PI/2 <= angle-forward <= PI/2

phi = −PI/2 −--> angle-forward = −PI/2 (aft)
phi = 0 −--> angle-forward = 0 (starboard)
phi = PI/2 −--> angle-forward = PI/2 (forward)

Starboard:

theta = angle-from-vertical

PI/2 <= phi <= 3*PI/2
is equivalent to
-PI/2 <= angle-forward <= PI/2

phi = PI/2 −--> angle-forward = −PI/2 (forward)
phi = PI −--> angle-forward = 0 (port)
phi = 3*PI/2 −--> angle-forward = PI/2 (aft)

V. Usage of Coordinate Systems in **MB-System**

Some sonar data formats provide angle values along with travel times. The angles are converted to takoff-angle coordinates regardless of the storage form of the particular data format. Currently, most data formats do not contain an alongtrack component to the position values; in these cases the conversion is trivial since phi = beta = 0 and theta = alpha. The angle and travel time values can be accessed using the **MBIO** function **mb_ttimes**. All angle values passed by **MB-System** functions are in degrees rather than radians.

The programs **mbbath** and **mbvelocitytool** use angles in take-off angle coordinates to do the raytracing. If roll and/or pitch corrections are to be made, the angles are converted to roll-pitch coordinates, corrected, and then converted back prior to raytracing.

BEAM FLAGS USED IN MB-SYSTEM

MB-System uses arrays of 1-byte "beamflag" values to indicate beam data quality. Each beamflag value is actually an eight bit mask allowing fairly complicated information to be stored regarding each bathymetry value. In particular, beams may be flagged as bad, they may be selected as being of special interest, and one or more reasons for flagging or selection may be indicated. This scheme is very similar to the convention used in the HMPS hydrographic data processing package and the SAIC Hydrobat package. The beam selection mechanism is not currently used by any **MB-System** programs.

The flag and select bits:
xxxxxx00 => This beam is neither flagged nor selected.
xxxxxx01 => This beam is flagged as bad and should be ignored.
xxxxxx10 => This beam has been selected.

Flagging modes:
00000001 => Flagged because no detection was made by the sonar.
xxxxx101 => Flagged by manual editing.
xxxx1x01 => Flagged by automatic filter.
xxx1xx01 => Flagged because uncertainty exceeds 1 X IHO standard.
xx1xxx01 => Flagged because uncertainty exceeds 2 X IHO standard.
x1xxxx01 => Flagged because footprint is too large
1xxxxx01 => Flagged by sonar as unreliable.

Selection modes:
00000010 => Selected, no reason specified.
xxxxx110 => Selected as least depth.
xxxx1x10 => Selected as average depth.
xxx1xx10 => Selected as maximum depth.
xx1xxx10 => Selected as location of sidescan contact.
x1xxxx10 => Selected, spare.
1xxxxx10 => Selected, spare.

SEE ALSO

mbsystem(l), **mbformat**(l)

BUGS

What could go wrong in a mere 204,289 lines of code?
Let us know...